calculatoratoz.com

unitsconverters.com

Strength and Stress Formulas

Calculators! Examples! Conversions!

Bookmark **calculatoratoz.com**, **unitsconverters.com**

Widest Coverage of Calculators and Growing - **30,000+ Calculators!**
Calculate With a Different Unit for Each Variable - **In built Unit Conversion!**
Widest Collection of Measurements and Units - **250+ Measurements!**

Feel free to SHARE this document with your friends!

Please leave your feedback here...

© calculatoratoz.com. A softusvista inc. venture!

List of 10 Strength and Stress Formulas

Strength and Stress

1) Bending Stress in Cotter of Cotter Joint

Open Calculator

fx $$\sigma_b = \left(3 \cdot \frac{L}{t_c \cdot b^2}\right) \cdot \left(\frac{d_2 + 2 \cdot d_4}{12}\right)$$

ex $$75.91516\text{N/mm}^2 = \left(3 \cdot \frac{50000\text{N}}{14\text{mm} \cdot (48.5\text{mm})^2}\right) \cdot \left(\frac{40\text{mm} + 2 \cdot 80\text{mm}}{12}\right)$$

2) Compressive Stress in Socket of Cotter Joint given Diameter of Spigot and of Socket Collar

Open Calculator

fx $$\sigma_{cso} = \frac{L}{(d_4 - d_2) \cdot t_c}$$

ex $$89.28571\text{N/mm}^2 = \frac{50000\text{N}}{(80\text{mm} - 40\text{mm}) \cdot 14\text{mm}}$$

3) Compressive Stress in Spigot of Cotter Joint Considering Crushing Failure

Open Calculator

fx $$\sigma_{c1} = \frac{L}{t_c \cdot d_2}$$

ex $$89.28571\text{N/mm}^2 = \frac{50000\text{N}}{14\text{mm} \cdot 40\text{mm}}$$

4) Compressive Stress of Spigot

Open Calculator

fx $$\sigma_{c1} = \frac{L}{t_c \cdot d_2}$$

ex $$89.28571\text{N/mm}^2 = \frac{50000\text{N}}{14\text{mm} \cdot 40\text{mm}}$$

5) Shear Stress in Cotter given Cotter Thickness and Width

Open Calculator

fx $$\tau_{co} = \frac{L}{2 \cdot t_c \cdot b}$$

ex $$36.81885\text{N/mm}^2 = \frac{50000\text{N}}{2 \cdot 14\text{mm} \cdot 48.5\text{mm}}$$

6) Shear Stress in Socket of Cotter Joint given Inner and Outer Diameter of Socket

Open Calculator

fx $$\tau_{so} = \frac{L}{2 \cdot (d_4 - d_2) \cdot c}$$

ex $$28.40909\text{N/mm}^2 = \frac{50000\text{N}}{2 \cdot (80\text{mm} - 40\text{mm}) \cdot 22\text{mm}}$$

7) Shear Stress in Spigot of Cotter Joint given Diameter of Spigot and Load

Open Calculator

fx $$\tau_{sp} = \frac{L}{2 \cdot a \cdot d_2}$$

ex $$26.59574\text{N/mm}^2 = \frac{50000\text{N}}{2 \cdot 23.5\text{mm} \cdot 40\text{mm}}$$

8) Tensile Stress in Rod of Cotter Joint

Open Calculator

fx $$\sigma t_{rod} = \frac{4 \cdot L}{\pi \cdot d^2}$$

ex $$66.24555 N/mm^2 = \frac{4 \cdot 50000 N}{\pi \cdot (31 mm)^2}$$

9) Tensile Stress in Socket of Cotter Joint given Outer and Inner Diameter of Socket

Open Calculator

fx $$(\sigma_t so) = \frac{L}{\frac{\pi}{4} \cdot (d_1^2 - d_2^2) - t_c \cdot (d_1 - d_2)}$$

ex

$$59.69551 N/mm^2 = \frac{50000 N}{\frac{\pi}{4} \cdot \left((54 mm)^2 - (40 mm)^2\right) - 14 mm \cdot (54 mm - 40 mm)}$$

10) Tensile Stress in Spigot of Cotter Joint given Diameter of Spigot, Thickenss of Cotter and Load

Open Calculator

fx $$(\sigma_t sp) = \frac{L}{\frac{\pi \cdot d_2^2}{4} - d_2 \cdot t_c}$$

ex $$71.77338 N/mm^2 = \frac{50000 N}{\frac{\pi \cdot (40 mm)^2}{4} - 40 mm \cdot 14 mm}$$

Variables Used

- **a** Gap between End of Slot to End of Spigot *(Millimeter)*
- **b** Mean Width of Cotter *(Millimeter)*
- **c** Axial Distance From Slot to End of Socket Collar *(Millimeter)*
- **d** Diameter of Rod of Cotter Joint *(Millimeter)*
- d_1 Outside Diameter of Socket *(Millimeter)*
- d_2 Diameter of Spigot *(Millimeter)*
- d_4 Diameter of Socket Collar *(Millimeter)*
- **L** Load on Cotter Joint *(Newton)*
- t_c Thickness of Cotter *(Millimeter)*
- σ_b Bending Stress in Cotter *(Newton per Square Millimeter)*
- σ_{c1} Compressive Stress in Spigot *(Newton per Square Millimeter)*
- σ_{cso} Compressive Stress In Socket *(Newton per Square Millimeter)*
- $\sigma_t so$ Tensile Stress In Socket *(Newton per Square Millimeter)*
- $\sigma_t sp$ Tensile Stress In Spigot *(Newton per Square Millimeter)*
- σt_{rod} Tensile Stress in Cotter Joint Rod *(Newton per Square Millimeter)*
- τ_{co} Shear Stress in Cotter *(Newton per Square Millimeter)*
- τ_{so} Shear Stress in Socket *(Newton per Square Millimeter)*
- τ_{sp} Shear Stress in Spigot *(Newton per Square Millimeter)*

© calculatoratoz.com. A softusvista inc. venture!

Constants, Functions, Measurements used

- Constant: **pi**, 3.14159265358979323846264338327950288
  Archimedes' constant
- Measurement: **Length** in Millimeter (mm)
  Length Unit Conversion
- Measurement: **Force** in Newton (N)
  Force Unit Conversion
- Measurement: **Stress** in Newton per Square Millimeter (N/mm²)
  Stress Unit Conversion

© calculatoratoz.com. A softusvista inc. venture!

Check other formula lists

- **Forces and Loads on Joint Formulas**
- **Joint Geometry and Dimensions Formulas**
- **Strength and Stress Formulas**

Feel free to SHARE this document with your friends!

PDF Available in

English Spanish French German Russian Italian Portuguese Polish Dutch

1/8/2024 | 9:35:50 AM UTC

Please leave your feedback here...

© calculatoratoz.com. A softusvista inc. venture!