Butt Welds Formulas...

1/9





Butt Welds Formulas

Calculators!

Examples!

Conversions!

Bookmark calculatoratoz.com, unitsconverters.com

Widest Coverage of Calculators and Growing - 30,000+ Calculators!

Calculate With a Different Unit for Each Variable - In built Unit Conversion!

Widest Collection of Measurements and Units - 250+ Measurements!

Feel free to SHARE this document with your friends!

Please leave your feedback here...





Open Calculator

Open Calculator

Open Calculator

List of 16 Butt Welds Formulas

Butt Welds M

1) Average Tensile Stress in Butt Weld

$$\sigma_{
m t} = rac{
m P}{
m L \cdot h_{
m t}}$$

 $ext{ex} \ 56.40274 ext{N/mm}^2 = rac{16.5 ext{kN}}{19.5 ext{mm} \cdot 15.002 ext{mm}}$

2) Efficiency of Butt Welded Joint G

$$\eta = rac{ ext{P}}{\sigma_{ ext{t}} \cdot ext{t}_{ ext{p}} \cdot ext{L}}$$

 $0.833485 = rac{16.5 ext{kN}}{56.4 ext{N/mm}^2 \cdot 18 ext{mm} \cdot 19.5 ext{mm}}$

3) Inner Diameter of Boiler given Thickness of Welded Boiler Shell 🛂

$$D_i = t \cdot 2 \cdot rac{\sigma_b}{P_i}$$

 $ag{1400} ext{mm} = 30 ext{mm} \cdot 2 \cdot rac{105 ext{N/mm}^2}{4.5 ext{MPa}}$



4) Internal Pressure in Boiler given Thickness of Welded Boiler Shell

 $\left| \mathbf{F}_{i} = t \cdot 2 \cdot rac{\sigma_{b}}{D_{i}}
ight|$

Open Calculator 🗗

 $ext{ex} 4.5 ext{MPa} = 30 ext{mm} \cdot 2 \cdot rac{105 ext{N/mm}^2}{1400 ext{mm}}$

5) Length of Butt Weld given Average Tensile Stress in Weld

 $\mathbf{L} = rac{\mathrm{P}}{\sigma_{\mathrm{t}} \cdot \mathrm{h_{t}}}$

Open Calculator

 $= 19.50095 \mathrm{mm} = rac{16.5 \mathrm{kN}}{56.4 \mathrm{N/mm^2 \cdot 15.002 mm}}$


6) Length of Butt Weld given Efficiency of Welded Joint

 \mathbf{f} $\mathbf{L} = rac{\mathbf{P}}{\mathbf{\sigma_t} \cdot \mathbf{t_p} \cdot \mathbf{\eta}}$

Open Calculator

 $ext{ex} 19.51135 ext{mm} = rac{16.5 ext{kN}}{56.4 ext{N/mm}^2 \cdot 18 ext{mm} \cdot 0.833}$

7) Permissible Tensile Stress in Butt Weld



 $ext{ex} egin{array}{l} 47.00855 ext{N}/ ext{mm}^2 = rac{16.5 ext{kN}}{19.5 ext{mm} \cdot 18 ext{mm}} \end{array}$










8) Permissible Tensile Stress in Butt Weld given Efficiency of Welded joint

$$\sigma_{
m t} = rac{
m P}{
m t_p \cdot L \cdot \eta}$$

Open Calculator

$$ext{ex} \ 56.43283 ext{N/mm}^2 = rac{16.5 ext{kN}}{18 ext{mm} \cdot 19.5 ext{mm} \cdot 0.833}$$

9) Strength of Butt Welded Joint



Open Calculator

$$ext{ex} \left[56.41026 ext{N} / ext{mm}^2 = rac{16.5 ext{kN}}{15 ext{mm} \cdot 19.5 ext{mm}}
ight]$$

10) Tensile Force on Butt Welded Plates given Thickness of Plate



Open Calculator 🚰

ex
$$16.4992 \mathrm{kN} = 56.4 \mathrm{N/mm^2 \cdot 19.5mm \cdot 15.002mm}$$

11) Tensile Force on Plates given Average Tensile Stress in Butt Weld


fx
$$P = \sigma_t \cdot h_t \cdot L$$

Open Calculator

$$\mathbf{ex} \ 16.4992 \mathrm{kN} = 56.4 \mathrm{N/mm^2 \cdot 15.002 mm \cdot 19.5 mm}$$



12) Tensile Force on Plates given Efficiency of Butt Welded Joint



Open Calculator 🗗

 $= 16.4904 \mathrm{kN} = 56.4 \mathrm{N/mm^2 \cdot 18mm \cdot 19.5mm \cdot 0.833}$

$\frac{10.4904\text{km}}{10.4904\text{km}} = \frac{10.41\text{mm}}{10.4904\text{km}} \cdot \frac{10.4904\text{km}}{10.833}$




 $\sigma_b = P_i \cdot rac{D_i}{2 \cdot t}$

Open Calculator

 $extbf{ex} 105 ext{N/mm}^2 = 4.5 ext{MPa} \cdot rac{1400 ext{mm}}{2 \cdot 30 ext{mm}}$


14) Thickness of Plate given Efficiency of Butt Welded Joint 🗹



Open Calculator 🖒

ex 18.01048mm = $\frac{16.5$ kN $\frac{16.5$ kN $\cdot 19.5$ mm $\cdot 0.833$

15) Thickness of Welded Boiler Shell given Stress in Weld



Open Calculator



16) Throat of Butt Weld given Average Tensile Stress 🛂



Open Calculator

$$\mathbf{h}_{\mathrm{t}} = rac{\mathrm{P}}{\mathrm{L} \cdot \mathbf{\sigma}_{\mathrm{t}}}$$

$$ext{ex} 15.00273 ext{mm} = rac{16.5 ext{kN}}{19.5 ext{mm} \cdot 56.4 ext{N/mm}^2}$$



Variables Used

- **b**_{ns} Beam Width for Nominal Shear (Millimeter)
- **D**_i Inner Diameter of Boiler (Millimeter)
- h_t Throat Thickness of Weld (Millimeter)
- L Length of Weld (Millimeter)
- P Tensile Force on Welded Plates (Kilonewton)
- Pi Internal Pressure in Boiler (Megapascal)
- **t** Thickness of Boiler Wall (Millimeter)
- t_n Welded Base Plate Thickness (Millimeter)
- n Efficiency of Welded Joints
- σ_b Tensile Stress in Boiler Butt Weld (Newton per Square Millimeter)
- σ_t Tensile Stress in Weld (Newton per Square Millimeter)





Constants, Functions, Measurements used

- Measurement: Length in Millimeter (mm)
 Length Unit Conversion
- Measurement: Pressure in Megapascal (MPa)
 Pressure Unit Conversion
- Measurement: Force in Kilonewton (kN)

 Force Unit Conversion
- Measurement: Stress in Newton per Square Millimeter (N/mm²)
 Stress Unit Conversion





Check other formula lists

- Butt Welds Formulas
- Parallel Fillet Welds Formulas Formulas
- Transverse Fillet Weld

Feel free to SHARE this document with your friends!

PDF Available in

English Spanish French German Russian Italian Portuguese Polish Dutch

7/29/2024 | 6:54:17 AM UTC

Please leave your feedback here...



