



# **Submerged Weirs Formulas**

Calculators!

Examples

Conversions!

Bookmark <u>calculatoratoz.com</u>, <u>unitsconverters.com</u>

Widest Coverage of Calculators and Growing - 30,000+ Calculators!

Calculate With a Different Unit for Each Variable - In built Unit Conversion!

Widest Collection of Measurements and Units - 250+ Measurements!

Feel free to SHARE this document with your friends!

Please leave your feedback here...





## **List of 17 Submerged Weirs Formulas**

## Submerged Weirs 3

1) Coefficient of Discharge given Discharge through Drowned Portion

$$\mathbf{K} \mathbf{C}_{\mathrm{d}} = rac{\mathrm{Q}_{2}}{\left(\mathrm{L}_{\mathrm{w}}\cdot\mathrm{h}_{2}
ight)\cdot\sqrt{2\cdot\mathrm{g}\cdot\left(\mathrm{H}_{\mathrm{Upstream}}-\mathrm{h}_{2}
ight)}}$$

Open Calculator 🗗

$$\boxed{0.659966 = \frac{99.96 m^3/s}{(3m \cdot 5.1m) \cdot \sqrt{2 \cdot 9.8 m/s^2 \cdot (10.1m - 5.1m)}}$$

2) Coefficient of Discharge given Discharge through Free Weir Portion

$$\boxed{\kappa} \mathbf{C_d} = \frac{3 \cdot Q_1}{2 \cdot L_w \cdot \sqrt{2 \cdot g} \cdot \left(H_{Upstream} - h_2\right)^{\frac{3}{2}}}$$

Open Calculator

3) Coefficient of Discharge if Velocity is Approached for Submerged Weir

$$\mathbf{K} \mathbf{C}_{\mathrm{d}} = rac{\mathrm{Q}_{2}}{\mathrm{L}_{\mathrm{w}} \cdot \mathrm{h}_{2} \cdot \left(\sqrt{2 \cdot \mathrm{g} \cdot \left(\mathrm{H}_{\mathrm{Upstream}} - \mathrm{h}_{2}
ight) + \mathrm{v}_{\mathrm{su}}^{2}
ight)}$$

Open Calculator

$$\boxed{0.60974 = \frac{99.96 \text{m}^3/\text{s}}{3 \text{m} \cdot 5.1 \text{m} \cdot \left(\sqrt{2 \cdot 9.8 \text{m/s}^2 \cdot (10.1 \text{m} - 5.1 \text{m}) + (4.1 \text{m/s})^2}\right)}$$

4) Coefficient of Discharge if Velocity is Approached given Discharge through Free Weir

$$\boxed{\mathbf{C}_{d} = \frac{3 \cdot Q_{1}}{2 \cdot L_{w} \cdot \sqrt{2 \cdot g} \cdot \left(\left(\left(H_{Upstream} - h_{2}\right) + \left(\frac{v_{su}^{2}}{2 \cdot g}\right)\right)^{\frac{3}{2}} - \left(\frac{v_{su}^{2}}{2 \cdot g}\right)^{\frac{3}{2}}\right)}}$$

Open Calculator 🚰

$$= \frac{3 \cdot 50.1 \text{m}^3/\text{s}}{2 \cdot 3 \text{m} \cdot \sqrt{2 \cdot 9.8 \text{m/s}^2} \cdot \left( \left( \left( 10.1 \text{m} - 5.1 \text{m} \right) + \left( \frac{(4.1 \text{m/s})^2}{2 \cdot 9.8 \text{m/s}^2} \right) \right)^{\frac{3}{2}} - \left( \frac{(4.1 \text{m/s})^2}{2 \cdot 9.8 \text{m/s}^2} \right)^{\frac{3}{2}} \right) }$$





#### 5) Discharge through Drowned Portion G

 $\left|\mathbf{Q}_{2}=\mathrm{C_{d}\cdot\left(L_{w}\cdot h_{2}
ight)\cdot\sqrt{2\cdot\overline{g\cdot\left(H_{\mathrm{Upstream}}-h_{2}
ight)}}}
ight|$ 

Open Calculator 2

 $\boxed{ \texttt{ex} \left[ 99.9651 \text{m}^3/\text{s} = 0.66 \cdot (3\text{m} \cdot 5.1\text{m}) \cdot \sqrt{2 \cdot 9.8 \text{m}/\text{s}^2 \cdot (10.1\text{m} - 5.1\text{m})} \right] }$ 

6) Discharge through Drowned Portion given Total Discharge over Submerged Weir

Open Calculator G

 $= 124.6 \mathrm{m}^3/\mathrm{s} = 174.7 \mathrm{m}^3/\mathrm{s} - 50.1 \mathrm{m}^3/\mathrm{s}$ 

fx  $\mathrm{Q}_2=\mathrm{Q}_\mathrm{T}-\mathrm{Q}_1$ 

7) Discharge through Free Weir if Velocity is Approached G

Open Calculator  $\mathbf{Q}_1 = \left(rac{2}{3}
ight) \cdot \mathbf{C}_{ ext{d}} \cdot \mathbf{L}_{ ext{w}} \cdot \sqrt{2 \cdot ext{g}} \cdot \left( \left( \left( \mathbf{H}_{ ext{Upstream}} - \mathbf{h}_2 
ight) + \left( rac{\mathbf{v}_{ ext{su}}^2}{2 \cdot ext{g}} 
ight) 
ight)^{rac{3}{2}} - \left( rac{\mathbf{v}_{ ext{su}}^2}{2 \cdot ext{g}} 
ight)^{rac{3}{2}} 
ight)^{rac{3}{2}}$ 

ex

$$\boxed{78.20741 \text{m}^3/\text{s} = \left(\frac{2}{3}\right) \cdot 0.66 \cdot 3\text{m} \cdot \sqrt{2 \cdot 9.8 \text{m/s}^2} \cdot \left(\left((10.1 \text{m} - 5.1 \text{m}) + \left(\frac{(4.1 \text{m/s})^2}{2 \cdot 9.8 \text{m/s}^2}\right)\right)^{\frac{3}{2}} - \left(\frac{(4.1 \text{m/s})^2}{2 \cdot 9.8 \text{m/s}^2}\right)\right)^{\frac{3}{2}} - \left(\frac{(4.1 \text{m/s})^2}{2 \cdot 9.8 \text{m/s}^2}\right)^{\frac{3}{2}} - \left(\frac{(4.1 \text{$$

8) Discharge through Free Weir Portion 🗗

 $\left|\mathbf{R}
ight| Q_1 = \left(rac{2}{3}
ight) \cdot C_d \cdot L_w \cdot \sqrt{2 \cdot g} \cdot \left(H_{Upstream} - h_2
ight)^{rac{3}{2}}$ 

Open Calculator 🚰

9) Discharge through Free Weir Portion given Total Discharge over Submerged Weir 🔄

fx  $\mathrm{Q}_1 = \mathrm{Q}_\mathrm{T} - \mathrm{Q}_2$ 

Open Calculator G


10) Discharge through Submerged Weir if Velocity is Approached

 $\left|\mathbf{K}
ight| Q_2 = C_d \cdot L_w \cdot h_2 \cdot \left(\sqrt{2 \cdot g \cdot (H_{Upstream} - h_2) + v_{su}^2}
ight)$ 

Open Calculator

 $\boxed{ 108.1995 \text{m}^3/\text{s} = 0.66 \cdot 3\text{m} \cdot 5.1\text{m} \cdot \left( \sqrt{2 \cdot 9.8 \text{m}/\text{s}^2 \cdot \left(10.1\text{m} - 5.1\text{m}\right) + \left(4.1\text{m}/\text{s}\right)^2} \right) }$ 





#### 11) Head on Downstream Weir for Discharge through Free Weir Portion 🗗

 $\mathbf{fz} egin{aligned} \mathbf{h}_2 = - \Bigg( rac{3 \cdot \mathbf{Q}_1}{2 \cdot \mathbf{C}_\mathrm{d} \cdot \mathbf{L}_\mathrm{w} \cdot \sqrt{2 \cdot \mathbf{g}}} \Bigg)^{rac{2}{3}} + \mathbf{H}_\mathrm{Upstream} \Bigg) \end{aligned}$ 

Open Calculator

$$= -\left(\frac{3\cdot 50.1 m^3/s}{2\cdot 0.66\cdot 3 m\cdot \sqrt{2\cdot 9.8 m/s^2}}\right)^{\frac{2}{3}} + 10.1 m$$

## 12) Head on Upstream Weir for Discharge through Drowned Portion

 $\boxed{\textbf{fx}} H_{\mathrm{Upstream}} = \left( \frac{Q_2}{C_d \cdot L_w \cdot h_2} \right)^2 \cdot \left( \frac{1}{2 \cdot g} \right) + h_2$ 

Open Calculator

# 13) Head on Upstream Weir given Discharge through Free Weir Portion

 $oxed{\mathbf{K}} \mathbf{H}_{\mathrm{Upstream}} = \left( rac{3 \cdot \mathrm{Q}_1}{2 \cdot \mathrm{C}_\mathrm{d} \cdot \mathrm{L}_\mathrm{w} \cdot \sqrt{2 \cdot \mathrm{g}}} 
ight)^{rac{2}{3}} + \mathrm{h}_2$ 

Open Calculator

#### 14) Length of Crest for Discharge through Drowned Portion

 $L_{w} = rac{Q_{2}}{C_{d} \cdot h_{2} \cdot \left(\sqrt{2 \cdot g \cdot (H_{Upstream} - h_{2}) + v_{su}^{2}}
ight)}$ 

Open Calculator



## 15) Length of Crest for Discharge through Free Weir

 $\mathbf{E}_{\mathrm{w}} = rac{3 \cdot Q_{1}}{2 \cdot C_{\mathrm{d}} \cdot \sqrt{2 \cdot g} \cdot \left( \left( \left( H_{\mathrm{Upstream}} - h_{2} 
ight) + \left( rac{v_{\mathrm{su}}^{2}}{2 \cdot g} 
ight) 
ight)^{rac{3}{2}} - \left( rac{v_{\mathrm{su}}^{2}}{2 \cdot g} 
ight)^{rac{3}{2}} 
ight)}$ 

Open Calculator

$$= \frac{3 \cdot 50.1 \text{m}^3/\text{s}}{2 \cdot 0.66 \cdot \sqrt{2 \cdot 9.8 \text{m/s}^2} \cdot \left( \left( (10.1 \text{m} - 5.1 \text{m}) + \left( \frac{(4.1 \text{m/s})^2}{2 \cdot 9.8 \text{m/s}^2} \right) \right)^{\frac{3}{2}} - \left( \frac{(4.1 \text{m/s})^2}{2 \cdot 9.8 \text{m/s}^2} \right)^{\frac{3}{2}} \right) }$$

16) Length of Crest for Discharge through Free Weir Portion

$$\mathbf{L}_{\mathrm{w}} = rac{3 \cdot \mathrm{Q}_{1}}{2 \cdot \mathrm{C}_{\mathrm{d}} \cdot \sqrt{2 \cdot \mathrm{g}} \cdot \left(\mathrm{H}_{\mathrm{Upstream}} - \mathrm{h}_{2}
ight)^{rac{3}{2}}}$$

Open Calculator

$$\boxed{ 2.300393 m = \frac{3 \cdot 50.1 m^3/s}{2 \cdot 0.66 \cdot \sqrt{2 \cdot 9.8 m/s^2} \cdot (10.1 m - 5.1 m)^{\frac{3}{2}} } }$$

17) Total Discharge over Submerged Weir

fx 
$$m{Q}_{
m T}=m{Q}_1+m{Q}_2$$

Open Calculator

$$150.06 \text{m}^3/\text{s} = 50.1 \text{m}^3/\text{s} + 99.96 \text{m}^3/\text{s}$$



#### Variables Used

- Cd Coefficient of Discharge
- **g** Acceleration due to Gravity (Meter per Square Second)
- h<sub>2</sub> Head on Downstream of Weir (Meter)
- Hupstream Head on Upstream of Weir (Meter)
- Lw Length of Weir Crest (Meter)
- Q<sub>1</sub> Discharge through Free Portion (Cubic Meter per Second)
- Q<sub>2</sub> Discharge through Drowned Portion (Cubic Meter per Second)
- Q<sub>T</sub> Total Discharge of Submerged Weir (Cubic Meter per Second)
- V<sub>SII</sub> Velocity over Submerged Weir (Meter per Second)





## Constants, Functions, Measurements used

- Function: sqrt, sqrt(Number) Square root function
- Measurement: Length in Meter (m)
  Length Unit Conversion
- Measurement: Speed in Meter per Second (m/s)
  Speed Unit Conversion
- Measurement: Acceleration in Meter per Square Second (m/s²)

  Acceleration Unit Conversion
- Measurement: Volumetric Flow Rate in Cubic Meter per Second (m³/s)

  Volumetric Flow Rate Unit Conversion





#### Check other formula lists

Broad Crested Weir Formulas

- Submerged Weirs Formulas
- Flow Over Rectangular Sharp-Crested Weir or Notch Time Required to Empty a Reservoir with Formulas 🚰
  - Rectangular Weir Formulas

Feel free to SHARE this document with your friends!

#### PDF Available in

English Spanish French German Russian Italian Portuguese Polish Dutch

1/20/2024 | 3:23:17 AM UTC

Please leave your feedback here...



