



Relationship between Stress and Strain Formulas

Calculators!

Examples!

Conversions!

Bookmark <u>calculatoratoz.com</u>, <u>unitsconverters.com</u>

Widest Coverage of Calculators and Growing - 30,000+ Calculators!

Calculate With a Different Unit for Each Variable - In built Unit Conversion!

Widest Collection of Measurements and Units - 250+ Measurements!

Feel free to SHARE this document with your friends!

Please leave your feedback here...





List of 19 Relationship between Stress and Strain Formulas

Relationship between Stress and Strain 🗗

1) Factor of Safety

$$\mathbf{f} \mathbf{x} \text{ F.O.S} = \frac{\mathbf{U}}{\mathbf{P}}$$

Open Calculator

$$=$$
 $4.083333 = \frac{49 \text{MPa}}{12 \text{MPa}}$

2) Margin of Safety

fx
$$M.O.S. = F.O.S - 1$$

Open Calculator

$$\boxed{\texttt{ex}} \, 3 = 4-1$$

3) Modulus of Elasticity given Compressive Stress

$$\mathbf{E} = \left(rac{\sigma_{
m c}}{arepsilon_{
m compressive}}
ight)$$

Open Calculator

$$\boxed{\mathbf{ex} 64 \mathrm{MPa} = \left(\frac{6.4 \mathrm{MPa}}{0.1}\right)}$$



4) Modulus of Elasticity given Normal Stress 🗗

 $\mathbf{E} = rac{\sigma_{\mathrm{n}}}{arepsilon_{\mathrm{component}}}$

Open Calculator 🚰

Open Calculator

Open Calculator

- $\boxed{\textbf{ex}} 96\text{MPa} = \frac{48\text{MPa}}{0.5}$
- 5) Modulus of Elasticity given Tensile Stress
- $\mathbf{E} = \left(rac{\sigma_{ ext{t}}}{arepsilon_{ ext{tensile}}}
 ight)$
- 6) Modulus of Rigidity given Shear Stress
- $\operatorname{f K} = \left(rac{ au}{\eta}
 ight)$
- $oxed{ex} 2.857143 \mathrm{MPa} = \left(rac{5\mathrm{MPa}}{1.75}
 ight)$



Open Calculator

Open Calculator

Open Calculator

Open Calculator

Strain 🗗

7) Compressive Strain given Compressive Stress

- $\epsilon_{
 m compressive} = \left(rac{\sigma_c}{E}
 ight)$
- 8) Lateral Strain given Decrease in Breadth
- $\epsilon_{
 m L} = rac{\Delta
 m b}{
 m b}$
- 9) Lateral Strain given Decrease in Depth
- $\epsilon_{
 m L} = rac{\Delta
 m d}{
 m d}$
- $ex 0.43 = \frac{43 \text{mm}}{100 \text{mm}}$
- 10) Lateral Strain using Poisson's Ratio
- fx $\epsilon_{
 m L} = -ig({f v} \cdot \epsilon_{
 m longitudinal} ig)$
- $extstyle -0.0186 = -(0.3 \cdot 0.062)$







11) Longitudinal Strain

fx $arepsilon_{
m longitudinal} = rac{\Delta L}{L_0}$

Open Calculator 2

Open Calculator 2

 $0.22 = \frac{1100 \text{mm}}{5000 \text{mm}}$

12) Shear Strain if Modulus of Rigidity and Shear Stress 🖸

 $0.138889 = \frac{5\text{MPa}}{36\text{MPa}}$

13) Tensile Strain given Modulus of Elasticity

 $\epsilon_{
m tensile} = \left(rac{\sigma_{
m t}}{
m E}
ight)$

Open Calculator

$\boxed{\mathbf{ex} \ 0.42375 = \left(\frac{3.39 \mathrm{MPa}}{8 \mathrm{MPa}}\right)}$

Stress 🛂

14) Compressive Stress given Compressive Strain 🗗

fx $\sigma_{
m c} = \left({
m E} \cdot \epsilon_{
m compressive}
ight)$ $0.8MPa = (8MPa \cdot 0.1)$







Open Calculator

Open Calculator

Open Calculator

Open Calculator 2

Open Calculator

Open Calculator

15) Normal Stress given Modulus of Elasticity G

fx $\sigma_{
m n} = \epsilon_{
m component} \cdot {
m E}$

 $ex 4MPa = 0.5 \cdot 8MPa$

16) Permissible Stress using Factor of Safety

 $\mathbf{E} \left[\mathbf{P} = \frac{\mathbf{U}}{\mathbf{F.O.S}} \right]$

= 12.25MPa = $\frac{49\text{MPa}}{4}$

17) Shear Stress given Shear Strain 🗗

fx $au = (\mathrm{G} \cdot \eta)$

 $= 63 MPa = (36 MPa \cdot 1.75)$

18) Tensile Stress given Modulus of Elasticity fx $\sigma_{
m t} = ({
m E} \cdot \epsilon_{
m tensile})$

 $ex 4.8MPa = (8MPa \cdot 0.6)$

19) Ultimate Stress using Factor of Safety

 $\mathbf{f} \mathbf{x} \mathbf{U} = \mathbf{F.O.S \cdot P}$ $48MPa = 4 \cdot 12MPa$

© calculatoratoz.com. A softusvista inc. venture!

Variables Used

- **b** Breadth of Component (Millimeter)
- **d** Depth of Component (Millimeter)
- E Modulus of Elasticity (Megapascal)
- F.O.S Factor of Safety
- G Modulus of Rigidity (Megapascal)
- **L**₀ Original Length (Millimeter)
- M.O.S. Margin of Safety
- P Permissible Stress (Megapascal)
- **U** Ultimate Stress (Megapascal)
- **\Delta b** Decrease in Breadth (Millimeter)
- Ad Decrease in Depth (Millimeter)
- ΔL Change in Length of Component (Millimeter)
- ε_{component} Strain in Component
- ξ_{compressive} Compressive Strain
- ε_I Lateral Strain
- ε_{longitudinal} Longitudinal Strain
- ε_{tensile} Tensile Strain
- σ_c Compressive Stress (Megapascal)
- σ_n Normal Stress (Megapascal)
- σ_t Tensile Stress (Megapascal)
- v Poisson's Ratio
- η Shear Strain





• τ Shear Stress (Megapascal)





Constants, Functions, Measurements used

- Measurement: Length in Millimeter (mm)
 Length Unit Conversion
- Measurement: Pressure in Megapascal (MPa)

 Pressure Unit Conversion
- Measurement: Stress in Megapascal (MPa)
 Stress Unit Conversion





Check other formula lists

- Direct Strains of Diagonal Formulas
- Elastic Constants Formulas
- Mohr's Circle Formulas
- Principal Stresses and Strains
 Formulas
- Relationship between Stress and Strain Formulas
- Strain Energy Formulas
- Thermal Stress Formulas
- Types of Stresses Formulas

Feel free to SHARE this document with your friends!

PDF Available in

English Spanish French German Russian Italian Portuguese Polish Dutch

9/20/2024 | 1:10:22 PM UTC

Please leave your feedback here...



